

Installation of Tyee Manufacturing vinyl windows and sliding patio doors.

These are general installation instructions for new construction BC wood framed single family homes. It is the installer's responsibility to perform proper installation of the product.

- All windows and doors are to be installed level, plumb, and square with minimum ¼" clearance on all sides.
- Sills must be fully supported with wood or plastic shims, no more than 6" from the corners and under all vertical mullions
 - Doors must be fully supported across the full width of the door.
- The bottom and sides of all windows and doors are to be nailed to the wood framing with 2 ½" galvanized roofing nails or equivalent screws. Nails to be placed no greater than 12" intervals on flanges less than 97" or no greater than 6" on flanges greater than 97".
- The header flanges of all windows and doors are to be fastened with 2" metal header clips at the same spacing as the bottom and side flanges. There is to be 3/8" clearance from the top of the flange to the step in the header clip

These instructions are meant to be a general guide for window installation. For specific installation requirements regarding weatherproofing please contact your envelope consultant.

Tyee Manufacturing assumes no responsibility for improperly installed products.